

藍芽系統適用之手機與功能一覽表

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
<b>AMOi</b>							
	N5000	OK	OK	OK	OK	OK	N5000
	A1	OK	OK	OK	OK	OK	A1
<b>Apple</b>							
	iPhone(3G)	OK	X	OK	OK	OK	
	iPhone(3G)	OK	X	OK	OK	OK	
<b>ASUS</b>							
	V70	OK	OK	OK	OK	OK	V70
	Ik03	OK	X	OK	OK	OK	Ik03
	V80	OK	X	OK	OK	OK	V80
	<b>P320</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>P320*9</b>
<b>BENQ-SIEMENS</b>							
	S55	OK	OK	OK	OK	OK	<b>S55, S56 *3</b>
	S65	OK	OK	OK	OK	OK	<b>S65 *3</b>
	<b>CL71</b>	OK	X	OK	OK	OK	CL71
	EF91	OK	OK	OK	OK	OK	EF91
	T51	OK	OK	OK	OK	OK	T51
	<b>M7</b>	OK	OK	OK	OK	OK	<b>M7*7</b>
	<b>E72</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	
	<b>T60</b>	OK	OK	OK	OK	OK	<b>T60*8</b>

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
<b>Black Berry(黑莓機)</b>							
	8300	OK	OK	OK	OK	OK	8300
	8120	OK	OK	OK	OK	OK	8120
<b>CHT</b>							
	3000	OK	OK	OK	OK	OK	3000
	<b>9100</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>9100*9</b>
	5000	OK	OK	OK	OK	OK	
<b>HP</b>							
	rw6816	OK	OK	OK	OK	OK	rw6816
<b>I-mate / Dopod</b>							
	<b>700</b>	OK	OK	OK	OK	OK	<b>PDA2K*7</b>
	<b>699</b>	OK	OK	OK	OK	OK	<b>Pocket PC*7</b>
<b>LG</b>							
	KG800	OK	OK	OK	OK	OK	KG800
	<b>C3380</b>	OK	<b>X2</b>	OK	OK	OK	C3380
	<b>G262</b>	OK	<b>X</b>	OK	OK	OK	G262
	KU800	OK	OK	OK	OK	OK	KU800

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
	KE590/KE590 I- mode/KE500	OK	OK	OK	OK	OK	KE590
	KE970/KE970c/KE 970d/KG70	OK	OK	OK	OK	OK	KE970
	KF510	OK	OK	OK	OK	OK	KF510
	KM501	OK	OK	OK	OK	OK	KM501
	KU250	OK	OK	OK	OK	OK	KU250
	KU990	OK	OK	OK	OK	OK	KU990
	KM380/KM380c/K M380T/KM385d/K M386c	OK	OK	OK	OK	OK	KM380
	KE770	OK	OK	OK	OK	OK	KE770
	KF350	OK	OK	OK	OK	OK	KF350
<b>Mio</b>							
	<b>A700</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>A700</b>
<b>Motorola</b>							
	<b>A760</b>	OK	<b>X1</b>	OK	OK	<b>X1</b>	<b>A760, A768, A760i, A768i</b>
	V600/V80	OK	OK	OK	OK	OK	V600, V500, V525, V80, E398, A630, E550, V535, V545, V550, V600i, V620
	V3	OK	OK	OK	OK	OK	V3
	E398	OK	OK	OK	OK	OK	E398
	E680i/E680	OK	OK	OK	OK	OK	E680i
	E1000	OK	OK	OK	OK	OK	E1000
	V360	OK	OK	OK	OK	OK	V360

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
	<b>A732</b>	OK	OK	OK	OK	OK	<b>A732*2</b>
	V3i	OK	OK	OK	OK	OK	V3i
	E770	OK	OK	OK	OK	OK	E770
	L6	OK	OK	OK	OK	OK	L6
	PBEL U6	OK	OK	OK	OK	OK	PBEL U6
	V361	OK	OK	OK	OK	OK	V361
	V501	OK	NA	OK	OK	OK	V501
	<b>明</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>明</b>
	E6	OK	NA	OK	OK	OK	E6
	KRZR K1	OK	NA	OK	OK	OK	KRZR K1
	Z3	OK	OK	OK	OK	OK	Z3
	W510	OK	OK	OK	OK	OK	W510
	<b>V8</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>V8</b>
	SLVR L72/L7i/L7e/L9	OK	OK	OK	OK	OK	L72
	RAZR maxx V1100/V3xx/V6	OK	OK	OK	OK	OK	V1100
	maxx V3	OK	OK	OK	OK	OK	V3
	<b>E8/U9/EM30</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>E8</b>
	<b>Q9H</b>	OK	<b>X</b>	OK	OK	<b>X</b>	Q9H
	V9/Z9/V3xxR/V9x	OK	OK	OK	OK	OK	V9
	ZN200	OK	OK	OK	OK	OK	ZN200
	<b>A810</b>	OK	<b>X</b>	OK	OK	OK	A810
	ZN5						ZN5
	V3x	OK	OK	OK	OK	OK	V3x
	<b>U9</b>	OK	OK	OK	OK	OK	<b>U9*7</b>
	A1800	OK	OK	OK	OK	OK	A1800

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
<b>NEC</b>							
	<b>N840</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>N840</b>
	<b>N500is</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>N500is</b>
<b>NOKIA</b>							
	<b>7610</b>	OK	OK	OK	OK	OK	<b>7610 *2</b>
	<b>7600</b>	OK	OK	OK	OK	OK	<b>7600 *2</b>
	<b>6230</b>	OK	OK	OK	OK	OK	<b>6230 *2</b>
	<b>6820</b>	OK	OK	OK	OK	OK	<b>6820 *2</b>
	<b>6600</b>	OK	<b>X2</b>	OK	OK	OK	6600
	8910i	OK	OK	OK	OK	OK	8910i
	<b>3650</b>	OK	<b>X2</b>	OK	OK	OK	<b>3650, 3660 *4</b>
	8910	OK	OK	OK	OK	OK	8910
	6310i	OK	OK	OK	OK	OK	6310i
	6310	OK	OK	OK	OK	OK	6310
	<b>6260</b>	OK	OK	OK	OK	OK	<b>6260 *2</b>
	<b>7280</b>	OK	OK	OK	OK	OK	<b>7280 *2</b>
	6680	OK	OK	OK	OK	OK	6680
	6230i	OK	OK	OK	OK	OK	6230i
	<b>6670</b>	OK	OK	OK	OK	OK	<b>6670 *2</b>
	N70	OK	OK	OK	OK	OK	N70
	6111	OK	OK	OK	OK	OK	6111
	6270	OK	OK	OK	OK	OK	6270
	7370	OK	OK	OK	OK	OK	7370
	6103	OK	OK	OK	OK	OK	6103
	6131	OK	OK	OK	OK	OK	6131

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
	6280	OK	OK	OK	OK	OK	6280
	<b>3250</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>3250</b>
	N73	OK	NA	OK	OK	OK	N73
	6151/6233/6234	OK	OK	OK	OK	OK	6151
	6288	OK	NA	OK	OK	OK	6288
	<b>5200</b>	OK	OK	OK	OK	<b>X</b>	5200
	6233	OK	OK	OK	OK	OK	6233
	7390	OK	OK	OK	OK	OK	7390
	E70	OK	OK	OK	OK	OK	E70
	6085	OK	OK	OK	OK	OK	3085
	5200	OK	OK	OK	OK	OK	5200
	N91	OK	OK	OK	OK	OK	N91
	E61	OK	OK	OK	OK	OK	E61
	3110	OK	OK	OK	OK	OK	3110
	E65	OK	OK	OK	OK	OK	E65
	<b>5310</b>	OK	<b>X</b>	OK	OK	OK	5310
	6500C	OK	OK	OK	OK	OK	6500C
	N70(New)	OK	OK	OK	OK	OK	N70
	<b>5700</b>	OK	OK	OK	OK	OK	<b>5700*7</b>
	5300	OK	OK	OK	OK	OK	5300
	N73	OK	OK	OK	OK	OK	N73
	3600s	OK	OK	OK	OK	OK	3600s
	6210 Navigator	OK	OK	OK	OK	OK	6210 Navigator
	2600c	OK	OK	OK	OK	OK	2600c
	2630	OK	OK	OK	OK	OK	2630
	2660	OK	OK	OK	OK	OK	2660
	2760	OK	OK	OK	OK	OK	2760

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
	6267	OK	OK	OK	OK	OK	6267
	6555	OK	OK	OK	OK	OK	6555
	7500 Prism	OK	OK	OK	OK	OK	7500 Prism
	3610 fold	OK	OK	OK	OK	OK	3610 fold
	<b>6121</b>	OK	OK	OK	OK	OK	<b>6121*7</b>
	<b>E51</b>	OK	OK	OK	OK	OK	<b>E51*7</b>
	<b>E66</b>	OK	OK	OK	OK	OK	<b>E66*7</b>
<b>2009/7/27</b>	<b>E71</b>	OK	OK	OK	OK	OK	<b>E71*7</b>
<b>2009/7/27</b>	<b>N82</b>	OK	OK	OK	OK	OK	<b>N82*7</b>
<b>2009/7/27</b>	<b>6124</b>	OK	OK	OK	OK	OK	<b>6124*7</b>
<b>2009/7/27</b>	5220	OK	OK	OK	OK	OK	5220
<b>2009/7/27</b>	7610S	OK	OK	OK	OK	OK	7610S
<b>2009/7/27</b>	7210C	OK	OK	OK	OK	OK	7210C
<b>O2</b>							
	<b>Zine</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>Zine</b>
	<b>Atom Life</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>xda Atom Life</b>
	<b>Xda Zinc</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>Xda Zinc</b>
<b>OKWAP</b>							
	<b>i900</b>	OK	<b>X</b>	OK	OK	OK	i900
	<b>S868</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>S868</b>
<b>Panasonic</b>							
	<b>X70</b>	OK	OK	OK	OK	OK	<b>X70, X88 *3</b>
	X700	OK	OK	OK	OK	OK	X700/X701

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
	X800	OK	OK	OK	OK	OK	X800
	VS7	OK	OK	OK	OK	OK	VS7
<b>PANTECH</b>							
	<b>PG-3600v</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>PG-3600v</b>
<b>Plam</b>							
	<b>Treo 680</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>Treo 680</b>
<b>PHS</b>							
	PG930	OK	OK	OK	OK	OK	PG930
<b>Sagem</b>							
	My X-6	OK	OK	OK	OK	OK	My X-6
	<b>My510x</b>	OK	<b>X</b>	OK	OK	OK	My510x
	<b>My700xi</b>	OK	<b>X</b>	OK	OK	OK	My700xi
<b>Samsung</b>							
	SGH- E738/E730/E736	OK	OK	OK	OK	OK	SGH-E738/E730/E736
	SGH- D500/508/500C/500 E	OK	OK	OK	OK	OK	SGH-D500/508/500C/500E
	SGH-E568	OK	OK	OK	OK	OK	SGH-E568
	SGH-D608	OK	OK	OK	OK	OK	SGH-D608
	SGH-D528	OK	OK	OK	OK	OK	SGH-D528



手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
	SGH-E908/D900	OK	OK	OK	OK	OK	E908
	SGH-D508	OK	OK	OK	OK	OK	D508
	SGH-P858	OK	OK	OK	OK	OK	SGH-P858
	SGH-D838	OK	OK	OK	OK	OK	SGH-D838
	SGH-Z238	OK	NA	OK	OK	OK	SGH-Z238
	SGH-E908	OK	NA	OK	OK	OK	SGH-E908
	SGH-E378	OK	NA	OK	OK	OK	SGH-E908
	SGH-Z248	OK	OK	OK	OK	OK	SGH-Z248
	SGH- L768/L760/L760V	OK	OK	OK	OK	OK	SGH-L768
	<b>SGH-J208/J200</b>	OK	OK	OK	OK	OK	<b>SGH-J208*7</b>
	SGH-i548B	OK	OK	OK	OK	OK	<b>SGH-i548B</b>
	<b>SGH-J408</b>	OK	X	OK	OK	OK	SGH-J408
	<b>SCH-F609</b>	X	X	X	X	X	<b>SCH-F609</b>
	<b>SGH-F268</b>	X	X	X	X	X	<b>SGH-F268*9</b>
	<b>SGH-i608</b>	X	X	X	X	X	<b>SGH-i608*a</b>
	SGH-U808	OK	OK	OK	OK	OK	SGH-U808
	SGH-F258	OK	OK	OK	OK	OK	SGH-F258
	<b>SGH-U908</b>	OK	OK	OK	OK	OK	<b>SGH-U908*7</b>
<b>SHARP</b>							
	GX-15	OK	OK	OK	OK	OK	GX-15
	GX-31	OK	OK	OK	OK	OK	GX-31
	T91	OK	OK	OK	OK	OK	T91
	T17	OK	NA	OK	OK	OK	T17
	<b>WX-T81</b>	OK	OK	OK	OK	OK	<b>WX-T81*7</b>

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
	<b>GX-T33</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>GX-T33*7</b>
<b>SonyEricsson</b>							
	<b>K700i/K700c</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>K700i/K700c</b>
	Z600	OK	OK	OK	OK	OK	Z600, Z608
	T610/T630	OK	OK	OK	OK	OK	T610, T618, T628, T630
	<b>P800</b>	OK	X1	OK	OK	X1	<b>P80x *1</b>
	<b>T68i(R6A,R8A)</b>	OK	OK	OK	OK	OK	<b>T68i *1</b>
	<b>T68i(R2A)</b>	OK	OK	OK	OK	OK	<b>T68i *1</b>
	<b>T68</b>	OK	OK	OK	OK	OK	<b>T68 *1</b>
	S700/S700i/S710a	OK	OK	OK	OK	OK	S700/S700i/S710a
	P900	OK	OK	OK	OK	OK	P900
	W550i	OK	OK	OK	OK	OK	W550i
	Z520i	OK	OK	OK	OK	OK	Z520i
	<b>K800i/K800xx</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>K800i/K800xx</b>
	<b>K750i/K750c/K750</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>K750i/K750c/K750</b>
	<b>D750</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>D750</b>
	<b>W800c/W800/W700</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>W800c/W800/W700</b>
	<b>Z800i/Z800c</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>Z800i/Z800c</b>
	Z550i	OK	OK	OK	OK	OK	Z550i
	W710i	OK	OK	OK	OK	OK	W710i
	W850i	OK	OK	OK	OK	OK	W850i
	Z610i	OK	OK	OK	OK	OK	Z610i
	Z710i/Z712a/Z710x	OK	OK	OK	OK	OK	Z710i/Z712a/Z710x
	K510i	OK	OK	OK	OK	OK	K510i
	K810i	OK	OK	OK	OK	OK	K810i

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
	W700i/W700c	X	X	X	X	X	W700i/W700c
	W850i/W850xx	OK	OK	OK	OK	OK	W850i/W850xx
	K550i/K550c/K550i m	OK	OK	OK	OK	OK	K550im
	K610i/K610im/K61 0xx	OK	OK	OK	OK	OK	K610i/K610im/K610xx
	K608i	OK	OK	OK	OK	OK	K608i
	W660i	OK	OK	OK	OK	OK	W660i
	K850i/K850a/K858c	OK	OK	OK	OK	OK	K850i
	K530i	OK	OK	OK	OK	OK	K530i
	Pli	OK	OK	OK	OK	OK	Pli
	M600i	X	X	X	X	X	M600i
	K660i	OK	OK	OK	OK	OK	K660i
	W910i	OK	OK	OK	OK	OK	W910i
	Z555	OK	OK	OK	OK	OK	Z555
	W380i	OK	OK	OK	OK	OK	W380i
	T303	OK	OK	OK	OK	OK	T303
	R306	OK	OK	OK	OK	OK	R306
	G700	OK	OK	OK	OK	OK	G700
	G502	OK	OK	OK	OK	OK	G502
	C902	OK	OK	OK	OK	OK	C902
	C702	OK	OK	OK	OK	OK	C702
	T700	OK	OK	OK	OK	OK	T700
	W980	OK	OK	OK	OK	OK	W980
	Z750i/Z750a	OK	OK	OK	OK	OK	Z750i/Z750a
	W902	OK	OK	OK	OK	OK	W902

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
<b>TOSHIBA</b>							
	<b>TS32</b>	OK	<b>X</b>	OK	OK	OK	TS32
	<b>G810</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>G810*a</b>
<b>vodafone</b>							
	1210	OK	OK	OK	OK	OK	1210
<b>Wmobile</b>							
	<b>GC909</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>X</b>	<b>GC909</b>

備註：

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
--------------------------	------	------------	--------------------------	------------	----------	--------------------------------	----------

- \*1：手機端藍芽設定須設定為進階模式，才可使用方向盤Switch 或 遙控撥號功能.
- \*2：Nokia7600/7610/6820/6230/6260 使用東信/台灣大哥大 SIM卡，通話結束時由發話方掛話，音響沒有回復，Moto A732使用中華電信SIM卡亦會有此問題。  
(此乃手機端系統與電信業者溝通問題). 必須由手機或搖控器或方向盤控制器掛話，音響才會正常回復.
- \*3：Call out 時，聲音預設在手機端，必須由手機端操作，聲音才會轉至免持聽筒端，此乃手機端系統設計緣故.
- \*4：手機當機率高.
- \*5：若可支援之藍芽手機功能與上述公布內容不符之問題，請洽怡利客服專線：0800079889
- \*6：BQB認證為藍芽SIG協會對藍芽產品的相容性認證，同一系列廠牌之手機通過認證代表其藍芽功能相容.
- \*7：通話時無法調整音量大小
- \*8：Call in 時,喇叭無來電鈴聲,接通後ok
- \*9: 配對完後s無法連線
- \*a: 配對時找不到s

**X**：完全不支援.

X1：本手機僅支援Headset-AG profile, 無此功能.

X2：手機傳送空白或錯誤 CallerId.

更新日期：2009/07/27

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報(來 電顯示)	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
--------------------------	------	------------	--------------------------	------------	----------	--------------------------------	----------

偶發狀況無法轉藍芽免持功能，此乃手機問題，測試原廠 **Car Kit** 亦有同樣情形。

This document was created with Win2PDF available at <http://www.daneprairie.com>.  
The unregistered version of Win2PDF is for evaluation or non-commercial use only.